




Proper Grounding for the M4x



WARNING: To avoid possible damage, the M4x Blade should be earth grounded or grounded to a rack that is earth grounded.

When installing and configuring the Blade, always make sure the lid is firmly attached using the captive fasteners located at the rear of the lid.

If the lid must be removed before it is earth grounded, be sure to ground the Blade. This can be done by attaching a 4-40 machine screw to any one of the three threaded holes on either side of the Blade (Figure 1). *Make sure the screw is no longer than 3/16 inches to avoid shorting any of the circuit boards inside the Blade.*



Figure 1